

Porta-Jump: Test, Charge & Drive

Quick Start Guide to a Safe Charge*

Make sure that all electrical accessories are turned off. Wait 5 minutes before going to Step 1. Your Porta-Jump should not be plugged into cigarette lighter at this time.

TEST

Step 1: Connect adapter plug, with switch in forward position, into your cigarette lighter or power port. Turn your Key (ignition) to the accessory (ACC) position. If green light on the adapter plug turns on, go to Step 2. If light does not turn on, professional assistance may be required.

CHARGE

Step 2: Keeping the adapter plugged into your car's outlet, plug the opposite end into the Porta-Jump unit. The green light should brighten. Wait 10 Minutes before going to Step 3.

DRIVE

Step 3: After 10 minutes of charge time, start your vehicle. Do **NOT** pump the gas pedal.

RECHARGE

Step 4: To recharge just reverse the switch on the adapter plug and after 30 minutes of drive time your unit will be fully charged.

STORAGE

Step 5: Return your unit to its storage bag and place in glove box.

*These are quick reference tips, refer to the product's back label for complete instructions, warnings, and disposal information.